

Purpose

Technique RRSNMTS sets whether mean miscellaneous time series data are to be printed.

Valid values are NO (0) and YES (1).

The Global default is NO (0).

This Technique is universal.

Form of Input

RRSNMTS(integer)

where integer is 1 or 0 specifying whether or not to print data

Example

RRSNMTS(1)

The mean miscellaneous time series data to be printed.